

Typical installation of detectors.



Microwave barrier with narrow detection zone can be used when customer want to have as much utilizable space as possible.

